


DiMarzio, Inc.


1388 Richmond Terrace, PO Box 100387, Staten Island, NY 10310, Tel(718)981-9286, Fax(718)720-5296

(Phase switch will change coils in single coil mode.)

on/on/on	phase switch
series	changes phase
single coil	changes coils
parallel	on/off




(Pickup will be in/out of phase with any other pickup in the guitar.)



on/on/on
series
single coil
parallel

(Phase switch makes the pickup out of phase with itself.)



phase switch	on/on/on
coils out of phase	series
changes phase of rd/bk coil	single coil
coils out of phase	parallel

Note: Tailpiece should be connected to common ground.
All grounds \perp must be connected.